

NO MORE DATA LEAKS due to misplaced portable drives

# Remote Management by DATALOCK®


for SecureDrive® BT and SecureUSB® BT

The DataLock® Remote Management console allows the admin to take full control of where and when the drive can be unlocked, the ability to remotely wipe data, and disable access - even if the user has a drive's PIN. All from a web console.

For your convenience, add the DataLock® Remote Management console to the SecureDrive® BT or SecureUSB® BT at any time.

## Remotely enforce security policies:

- Where/When drives allowed to be used
- Wipe Drives
- Disable access
- Remotely unlock/Force password reset
- Track and Manage unlimited number of drives



## MAIN FEATURES



### GEO-FENCING

The admin for the account can limit access to the user by any of the following: Continent, Country, Address, City, State or Zip Code. Once an admin sets geo-location by selecting the radius (KM/MI) the fencing is complete. Geo-fencing is based on the precision of the GPS chips used in the mobile devices (vs. IP address-based geo-fencing used by competitors).



### TIME FENCING

The Admin for the account can limit access for the user by setting start/end time limitations in any time zone.



### DUAL FACTOR AUTHENTICATION

Unique dual factor authentication method via User Account and Drive PIN/Password combination. For managed drives, each user must have their unique usernames and passwords to access the DataLock® mobile app. Once authenticated the user must also possess the correct drive PIN/password to unlock the device.



### USER LOGGING

Admins can easily monitor all logins and unlock attempts. Admins also see the date, time, and exact coordinates of any login or unlock attempts.

Learn more at [securedrive.com/rm](https://securedrive.com/rm)





# REMOTE MANAGEMENT

## ADDITIONAL ADMIN FEATURES



### REMOTE WIPE

Admin Remote Wipe: remotely crypto-erase all data on the selected drive including the user's credentials.



### REMOTE UNLOCK

Admin Remote Unlock: remotely unlocks the drive using the Admin's credentials.



### PASSWORD CHANGES

Change User's Password: resets a user's password remotely. No data is lost.




### DISABLE ACCESS

Admin can disable access to a drive even if the user has a drive PIN.

## HOW IT WORKS

### Step 1



Admin inputs command on Remote Management Web Console pertaining to a user/drive



### Step 2



The command is sent in an encrypted signal from the server to the DataLock app



### Step 3



User enters credentials into DataLock app to authenticate permission and unlock the drive



### Step 4



DataLock app receives the admin command and transmits to the drive via encrypted Bluetooth signal



**SECUREDATA, Inc.**  
3255 Cahuenga Blvd. W, #111  
Los Angeles, CA 90068, USA

Website: [securedrive.com](http://securedrive.com)  
E-mail: [support@securedrive.com](mailto:support@securedrive.com)

Toll Free: **1-800-875-3230**  
International: **+1-323-944-0822**

