

## More Online

For more features and for troubleshooting, see the SecureDrive-BT User Manual on our website.

<https://www.securedrive.com/documents/user-manual-bt.pdf>

NOTE: For security, we strongly suggest changing the factory password to a new password.



[www.securedrive.com](http://www.securedrive.com)  
[help@securedata.com](mailto:help@securedata.com)

Rev. 20190204A

USA: 1-800-875-3230  
International: +1-323-944-0822

**SECURE DRIVE**  
BLUETOOTH®



# SecureDrive BT

## Quick Start Guide









Welcome to SecureDrive™ BT Model, our app-operated, hardware encrypted, external portable storage that's OS-independent. It's controlled via smartphone (iOS, Android).

### 1. Installing the App



Download and install the "DataLock" App from either Apple's App Store or Google Play.



**CAUTION:** Risk of loss of data. If you forget your password, all data will be inaccessible and reformatting will be required.







|   |  |   |                                 |
|---|--|---|---------------------------------|
|  Red LED is ON, solid    | The drive is locked or may indicate procedure failed |  Blue LED is blinking  | Transferring data               |
|  Red LED is blinking    | Locked or ready for input                            |   | Represents the LED on the drive |
|  Green LED is ON, solid | Drive is unlocked                                    |   | Represents the icons in the app |

## 2. Adding the Drive to the App (Pairing)

- Connect the Drive to a computer with the USB cable. 
- Start the app, tap the Drive name and follow the on-screen instructions. 

## 3. Unlocking the SecureDrive-BT



With the app running, after tapping the drive name:

- Enter password (the factory preset `11223344`)   
- Tap unlock.   

NOTE: After 10 failed attempts to unlock it, the drive will be erased (reset). Refer to Brute Force Hacking in the User Manual.

## Changing the Password

After unlocking the drive in the app:  

- Tap the desired drive name.
- Tap **Change Password** and enter your current password.
- Enter your new password (see requirements below) and then retype it into the Confirm field.
- Tap **Change Password**.  

### PASSWORD REQUIREMENTS

- 7-15 digits, special characters okay
- Cannot all be the same number/letter or consecutive numbers/letters.

## Disconnecting and Locking

Unplug the cable—the Drive locks automatically.

Generally, ejecting it first is not necessary.

To lock the Drive without unplugging it, swipe the Drive name left and tap **Lock**. 